Auckland: (09) 2717 234
Christchurch: (03) 741 6241

sales@machineryhouse.co.nz
www.machineryhouse.co.nz

Product Brochure For L451

Lathe Turning Tool Kit - 3 piece Insert Type

16mm Tool Height

Ex GST	Inc GST
$273.04	$314.00



ORDER CODE:	L451
Type:	Turning Tool Kit
Tool Type:	Carbide Inserts
Shank Size - Tool Height (mm):	16
Pieces in Set (No.):	3
Replacement Tip Code:	L062
Nett Weight (kg):	1.2

Made in Taiwan

Description

Compact turning kit with right hand and left hand turning tools and a boring bar. The kit is designed so that all the tools use the same inserts. The inserts used in this kit are ISO standard and can be substituted with any of the major brands of inserts.

16mm Tool Height

Includes

- 1 x 16mm Right hand turning tool STGCR1616H11
- 1 x 16mm Left hand turning tool STGCL1616H11
- 1 x 16mm Right hand boring bar S16QSTFCR11
- 10 x inserts to suit all tools(TCMT110204)

Optional Accessories

- Replacement Inserts use (L062)
- Replacement Screw use (L525)
- Replacement Key T-7 use (L526)

Auckland: (09) 2717 234
Christchurch: (03) 741 6241

sales@machineryhouse.co.nz
www.machineryhouse.co.nz

Product Brochure For L451

SETTING THE SPINDLE SPEED

To calculate the correct speed the following metric formula can be used

$$RPM = \frac{1000 \times \text{Surface speed in Metres per Minute}}{3.14 \times \text{Diameter in millimetres}}$$

Approximate surface speeds for carbide tools	Metres per minute	
Material	**Roughing**	**Finishing**
Mild Steel	50	80
Cast Iron	40	60
Aluminium	80	100
Stainless Steel	40	50

Example 1.
20mm Mild Steel bar to be rough machined

$$RPM = \frac{1000 \times 50}{3.14 \times 20mm} = \frac{50000}{62.8} = 796rpm$$

Example 2.
20mm Mild Steel bar to be finished machined


$$RPM = \frac{1000 \times 80}{3.14 \times 20mm} = \frac{80000}{62.8} = 1273rpm$$

- Set the spindle speed to the closest speed to the RPM calculated
- If in doubt then set a speed slower than the calculated speed


SETTING THE TOOL ON CENTRE

For the tool to cut correctly it needs to be set on centre. This can be best achieved by placing a centre in the tailstock and packing the tool until the tool is on centre.

Correct centre height



Incorrect centre height



Specific Features



Set

Auckland: (09) 2717 234
Christchurch: (03) 741 6241

sales@machineryhouse.co.nz
www.machineryhouse.co.nz

Product Brochure For L451

Recommended Accessories

L062
KYOCERA Carbide Inserts - Turning



L525
Screw to Suit Turning Tool Holder



L526
Key to Suit Tool Holder



L017
Right Hand Turning Tool Holder



L018
Left Hand Turning Tool Holder




L022
Right Hand Boring Bar



L450
Lathe Turning Tool Kit - 3 piece Insert Type



L452
Lathe Turning Tool Kit - 3 piece Insert Type



Auckland: (09) 2717 234
Christchurch: (03) 741 6241

sales@machineryhouse.co.nz
www.machineryhouse.co.nz

Product Brochure For L451

L453
Lathe Turning Tool Kit - 3 piece Insert Type



L072
HSS Turning Tool Set - 4 piece



L0085
Carbide Turning Tool Set - 11 piece



L0055
Lathe Turning Tool Kit - 5 piece Insert Type



L0099
Lathe Turning Tool Kit - 7 piece Insert Type



L0077
Lathe Turning Tool Kit - 7 piece Insert Type



L456
Lathe Threading Tool Kit - Insert Type



L457
Lathe Threading Tool Kit - Insert Type



L458
Lathe Threading Tool Kit - Insert Type



L459
Lathe Threading Tool Kit - Insert Type



L464
Professional Lathe Parting Tool Kit - Insert Type



L465
Professional Lathe Parting Tool Kit - Insert Type



Auckland: (09) 2717 234
Christchurch: (03) 741 6241

sales@machineryhouse.co.nz
www.machineryhouse.co.nz

Product Brochure For L451

L466
Professional Lathe Parting Tool Kit - Insert Type



L467
Professional Lathe Parting Tool Kit - Insert Type



L006A
Boring Bar Set - HSS



L431
Boring Bar Set - Carbide Insert



L430
Boring Bar Set - Carbide Insert

